

# Instructions for Erecting Tent

1. Unpack the bell tent
2. Lay out the ground sheet as flat as possible.
3. Lift tent onto the ground sheet.
4. Locate the entrance, and place it in the direction you want your tent to face.
5. Peg down the two peg loops on either side of the entrance with a peg to secure its position.
6. Now go round the base of the tent, pinning down the other loops with the pegs following the edge of the ground sheet.
7. Locate the poles; join the two sections of the longer central pole together.
8. Take the central pole inside the still flat tent, locate apex of tent and push the pole up into it, push up the tent until pole vertical.
9. From the outside, place the smaller pole in the entrance.
10. Guy out the two front guy ropes, and then the other ropes. Remember to follow the seam of the tent outwards when pegging out these guy ropes.

**Stand back and enjoy your newly erected  
FBA Sahara Bell Tent**